

WANDSWORTH COMMON



DOWN RUNNING SIGNALS—continued

11. Down Local Inner Home (Platform Starting)
12. Down Local to Down Through Inner Home (Platform Starting and Junction Indicator 45° Upper Quadrant to Right.)
17. Down Through Outer Home.
18. Down Through to Down Streamline Hill Inner Home (Platform Starting and Junction Indicator 90° to Left.)
19. Down Through to Down Local Inner Home (Platform Starting and Junction Indicator 45° Upper Quadrant to Left.)
20. Down Through Inner Home (Platform Starting).

1. From Up Local to Down Local over Points 2.

1. From Up Local to Down Local over Points 2.
2. From Down Local to Up Local over Points 2.
3. From Down Sliding to Down Local over Points 5.
4. From Down Sliding to Down Local over Points 5.
5. Back on Down Local or to Down Sliding.
6. From Up Local to Down Streamline Hill or Down Local over Points 23.
7. From Down Local to Up Local over Points 23.
8. Along Up Sliding.
9. Along Up Sliding.

1

5. Sreatham to Up Main Inner Home.
5. Sreatham to Herne Hill Inner Home.
20 Up Main Starting.

Herne Hill to Streatham Starting.

3. Down
Indica